

**HEATED
HOT & COLD
DISPLAY UNITS**
USER MANUAL



We would like to thank you for trusting us and purchasing this refrigerated unit. This manual has been prepared in order to provide the security of the user and ensure the correct use and maintenance of the refrigerated units. Please read it carefully before starting up your unit.

CONTENTS

1.GENERAL	8
2.GUARENTEE	9
3.SAFETY AND CONTROL.....	9
4.INSTALLATION	10
5.MAINTENANCE AND CLEANING.....	11
6.CAUTIONS	12
7.MAJOR PARAMETERS	12

1. GENERAL

This manual is considered to be an integral part of the refrigerated unit and as such, should be kept in a safe place. The certificate of guarantee is included inside this user maintenance manual together with the registration number of the unit. In the event of loss, please request a duplicate by indicating the model, serial number and date of purchase. Before carrying out any operation, whether as installation technician or as the user of the unit, you should be aware of the points explained in this manual. The manufacturer considers that both the installation technician and the user of the unit must have the most basic training in order to understand the contents of this manual, as well as an awareness of standard hygiene and safety principals. If required, this unit must be repaired exclusively by qualified technical personnel. If you have any question about the content of this manual, please contact the distributor or the manufacturer.

The user will be responsible for the following items:

- Suitability of the premises to the requirements of the purchased unit.
- Electricity supply in accordance with the current standards and
sufficient for the consumption and safety of the unit.
- Necessary material to clean the unit.
- Water point or drainage outlet as necessary for the installation of
the refrigerated unit. The manufacturer disclaims all liability
in the following situations:
 - Inappropriate use of the purchased unit.
 - Installation not carried out following the procedures described in this manual.
 - Defects in the electricity supply.
 - Unauthorised modifications or interventions.
 - Use of spares not specific to the model.
 - Total or partial non-compliance with the instructions.
 - Incidents caused by the transportation company or movement of the unit to its
place of installation.

2. GUARENTEE

The guarantee for the unit and the parts that comprise it, is for one year starting from the date of sale, consists of the replacement (carriage unpaid) of the defective component or components, providing that, it is not the result of the misuse of it. The guarantee will not cover breakdown or breakage of components, even if it occurs within the established period, arising from subjecting the unit to working conditions other than those established in this manual and the details of each model contained in the catalogue (failure in the power supply, high ambient temperatures, windows, lighting, etc...).

3. SAFETY AND CONTROL

In order to inspect the unit, before starting it up, the following checks should be taken into account:

- Do not modify the specifications of plate or instructions issued by the manufacturer.
- Do not remove or modify the safety elements.
- Do not touch the unit with wet or damp hands and feet.
- Do not touch the unit when barefoot.
- Do not pull the cable to unplug the unit.
- Before carrying out any cleaning or maintenance operation, unplug the unit from the electricity supply, first turning off the main switch and then unplugging the unit.
- The unit should not be used in threatening atmosphere or fire risk conditions.
- Avoid the use of adapters, extension leads or multiple plugs.
- The unit must not be used by children, persons whose mental, sensory or physical capacities are impaired. Persons who lack experience or knowledge must be supervised or given instructions for use.
- Check that the voltage and power line frequency coincide with those indicated on the specification plate of the appliance.
- Check that if there are not defects on the unit resulting from its transportation. The manufacturer will not be liable for damage suffered during transportation or arising from incorrect storage.
- Check the operation of the moving components of the unit.
- Check the safety of the control board, electrical cables and connections.
- Check that all the interior and additional accessories are present.



4. INSTALLATION

4.1 INSTALLATION

Before connecting the unit to the power supply, check that if the voltage and the power line frequency coincide with those indicated on the specification plate of the appliance. **It is essential that the electrical installation to which the unit is going to be connected, has an EARTH LEAD, as well as the necessary thermal and differential magnetic protection. The power supply must have the suitable section for the consumption of the appliance.** When the unit is connected and started-up, depending on the model, a control light is displayed on the switchboard. If various units are installed in a row, each one must be connected independently to the power supply, avoiding the use of extension leads or multiple plugs. The manufacturer disclaims all liability, when any of the above points are not followed.

5. MAINTENANCE AND CLEANING

5.1 MAINTENANCE

Before carrying out any cleaning operation, disconnect the unit from the power supply and place the main switch in the OFF or 0 position. The units are equipped with a drainage outlet to make cleaning easier, as well as allowing for the eventual seepage of liquids from the foods. The good operation and performance of the unit will largely depend on its correct maintenance, carried out periodically. The manufacturer is exempt from all liability arising from non-compliance with the procedures contained in this manual.



5.2 CLEANING

First remove the pre-cut protective film from the steel, using any blunt implement. The first cleaning should be carried out using a cloth dampened in water and neutral soap. **DO NOT USE DETERGENTS OR ABRASIVE PRODUCTS**, taking special care not to wet the electric components.

Totally avoid the use of utensils or elements that could scratch or damage the unit.

We recommend that the cleaning of the outside of the unit should be done on a daily basis and with a damp cloth.

When it is cleaned and dried, place the accessories in their proper places.

6. CAUTIONS

Please do not use steel wire or nickel sponges to clean **STAINLESS STEEL** or leave them lying on the surface as the iron deposits can stick and cause formation of rust contamination, thus jeopardise the hygiene of the surface.

7. MAJOR PARAMETERS

PARAMETER	PRODUCT
TEMPERATURE RANGE	30-90
RATED VOLTAGE (V)	220-240
RATED FREQUENCY (Hz)	50